

Hints & Tips

Bullet Head Nails

Skew nail to maximise joint strength and avoid end grain nailing. Use longer length nails in softwood to achieve equal strength.