

Hints & Tips

Wood Screws

- For 4G screws drill a 2.0mm pilot hole
- For 5G screws drill a 2.5mm pilot hole
- For 6G screws drill a 2.5mm pilot hole
- For 7G screws drill a 3.0mm pilot hole
- For 8G screws drill a 3.0mm pilot hole
- For 10G screws drill a 3.5mm pilot hole
- For 12G screws drill a 4.5mm pilot hole
- For 14G screws drill a 5.0mm pilot hole