

Installation Instructions

Anti-Sag Kit

TOOLS REQUIRED:

- Drill
- Phillips Head Screwdriver
- Adjustable or open face wrench

INSTRUCTIONS

IMPORTANT please read the instructions before you install gate kit.

Fits gates with a diagonal measurement up to two metres.

1. Place one corner bracket on upper hinge corner of gate, place the other corner bracket on lower opposite corner and mark screw holes. Using a 2.5mm drill bit, drill pilot holes no longer than the screws being used. Fasten bracket to gate.
2. Place turnbuckle hook through the hole in upper corner bracket, with the hook opening facing away from the gate.
 - Make sure turnbuckle is extended to maximum length. Place cable through turnbuckle eye, then attach cable clamp and tighten.
3. Place cable through hole in lower bracket and pull cable taut. Attach cable clamp and tighten.
4. Tighten turnbuckle to eliminate gate sag.
5. Where your Zenith Anti-Sag Gate Kit is installed with a metal gate and fence, fix with suitable self-tapping screws or rivets.