

## Installation Instructions

### Ball Bearing Timber Gate To Timber Post

1. Position hinge on gate and check that unit will function as intended
2. Mark and drill 5.5mm pilot holes for coach screws.
3. Fasten hinge using coach screws provided.
4. Repeat fixing to post