

Installation Instructions

Decking Screws

1. Choose a screw long enough to provide a minimum of 25mm thread embedment into the timber being fastened to.
2. To prevent timber splitting pre-drill a 3.5mm pilot hole and countersink when fixing butt joints and ends. For composite decking pre-drill and countersink for all screws.
3. Fit screw to a power screw driver and set to Low and place at fastening position.
4. Push sharply to create a starting point.
5. Apply firm and even pressure until head is flush with surface - do not over torque.