

Installation Instructions

Gate Hooks

1. Position hook in desired location to check that unit will function as intended.
2. Mark and drill pilot hole for eye using a 3/32" (2.5mm) drill bit. Screw eye into pilot hole.
3. Mark and drill pilot hole for hook using a 3/32" (2.5mm) drill bit. Screw hook into pilot hole.