

## Installation Instructions

# Hinges – Colonial Tee / Decorative

1. Position item in place and check that unit will function as intended.
2. Mark and drill 5.5mm pilot holes for coach screws.
3. Fix item to gate by tightening coach screws using a 13mm spanner. Repeat for second hinge.
4. Repeat procedure for fixing hinges to gate post.