

## Installation Instructions

# Metal Screws - Buildex

1. Fit screw to a power driver and set to High (driving too slowly may result in the wings not breaking off). Place screw at fastening position.
2. Push sharply on screw driver to create a starting point.
3. Squeeze screwdriver trigger and maintain firm end pressure until the screw has drilled and fastened.