

Installation Instructions

Plasterboard Screws - Buildex

1. Choose a screw long enough to allow at least three threads to protrude beyond the metal being fastened to.
2. Fit screw to a power screw driver and set to High and drive home. Do not overdrive.