

Installation Instructions

Plasterboard Screws - Zenith

1. Choose a screw length that will provide sufficient embedment into the timber.
2. Drive screw with a power drill set at High Speed. Do not overdrive.