

Installation Instructions

Polished Brass H&S

1. Position Hasp & Staples in location to check that unit will function as intended.
2. Mark position for screws and drill 2.5mm pilot holes using a drill
3. Fit unit using screws provided.