

## **Installation Instructions**

## **Roofing & Cladding Screws**

- 1. Choose a screw long enough to allow embedment into the wood/metal being fastened to.
- 2. Fit screw to a power screw driver and set to High. Place screw at fastening position.
- 3. Push sharply on screw driver to create a starting point.
- 4. Squeeze screwdriver trigger and maintain firm end pressure until the screw has drilled and fastened.