

Installation Instructions

Screws

Bugle Batten / Chipboard / Decking / Metal / Roofing & Cladding / Timber

1. Choose a screw long enough to allow embedment into the wood being fastened to.
2. Fit screw to a power screw driver and set to High. Place screw at fastening position.
3. Push sharply on screw driver to create a starting point.
4. Squeeze screwdriver trigger and maintain firm end pressure until the screw has drilled and fastened.