

## Installation Instructions

### Screws – Chipboard / Treated Pine

1. Choose a screw long enough to provide approximately 20mm thread embedment into the timber being fastened to.
2. Fit screw to a power screw driver and set to Low and place at fastening position.
3. Push sharply to create a starting point.
4. Drive screw home until head is flush with surface.