

Installation Instructions

Single Eye Padbolt (& With Padlock)

1. Position padbolt and saddle in location to check that unit will function as intended.
2. Fasten padbolt to gate with screws provided using a no. 2 Phillips bit at 1,000 RPM (alternatively you can use a standard screwdriver). Mark holes for screws, drill 2.5mm pilot holes and fasten using screws provided and a Phillips head screwdriver.
3. Fit saddle to gate post.