

Installation Instructions

Split Drive Anchor

- 1. Drill hole to correct diameter and depth.
- 2. Clean thoroughly with brush. Remove debris by way of vacuum, hand pump, compressed air etc.
- 3. Insert Split-Drive into hole through fixture and nail home against fixture.