

## **Installation Instructions**

## **Threaded Rods & Couplers**

- 1. Pre-drill materials being fastened.
  - Manual fixing with a ring spanner is recommended.
- 2. Join materials together by placing a nut on either end.