

Installation Instructions

Wallmate - Buildex

1. Place Wall-Mate on the end of a Phillips head screw driver.
2. Put point of Wall-Mate where the anchor is to be installed, and lightly pierce the plasterboard face paper. Using firm pressure, screw Wall-Mate into the plasterboard until head is tight against the face paper.
3. Choose a screw or hook suitable for the particular application. Attach the item to be fixed by driving the screw into the Wall-Mate.