

Installation Instructions

Wood Screws

1. Drill pilot hole through materials being joined
2. Drill shank hole through material being fastened
3. Manual drive recommended