

## Good To Know

### SureHook – U & J Shape

\*Max weight load when hook is fastened into 10mm plasterboard, timber stud or masonry wall with specified fasteners in both top and bottom hole locations. Plasterboard quality will deteriorate with frequent hook use, place load gently on hook to minimise impact to wall. ITW Proline shall not be liable for any fastening failure due to improper installation or use, exceeding maximum load stated or defective building materials.