

Hints & Tips

Coach Screws

Handy tips:

- Drill the pilot hole 2mm smaller than the size Coach Screw being used.
- Do not over tighten the screw as this could cause it to break.
- For timber to timber connections, a washer is recommended to use under the head to prevent it from getting damaged during installation and crushing of the timber.