

Hints & Tips

Flat Head Nails

When nailing into hardwood, drill pilot holes using a slightly smaller diameter than the nail shank.