

## Installation Instructions

# Double Eye Padbolt

1. Position padbolt and saddle in location to check that unit will function as intended.
2. Fasten padbolt to gate with screws and carriage bolts provided using a no.2 Phillips bit at 1,000 RPM (alternatively you can use a standard screwdriver). Mark holes for screws, drill 3.5mm pilot holes and fasten using screws provided and a Phillips head screwdriver. To fit Carriage Bolts 6mm holes are recommended.
3. Fit saddle to gate post.