

Installation Instructions

External Screws / Hinge Screws

1. Choose a screw length that will provide sufficient embedment into the timber being fastened to.
2. Fit screw to driving tool. Push sharply to create "centremark".
3. Squeeze trigger and maintain constant pressure until screw has drilled and fastened.