

Installation Instructions

Hasp & Staple – Concealed Fix

1. Position hasp and staple in location to check that unit will function as intended.
2. Fasten with screws provided using a no.2 Phillips bit at 1,000 RPM (alternatively you can use a standard screwdriver). Mark holes for screws, drill 3mm pilot holes and fasten using screws provided and a Phillips head screwdriver.
3. Use a 7mm drill bit for fix bolt.