

## Installation Instructions

# Nuts, Washers, and Specialty Fasteners

1. Pre-drill materials being fastened. Manual fixing with a ring spanner is recommended.
2. Place a washer under both nut and bolt head.