

Installation Instructions

Rivets

1. Drill hole through material to be fastened.
2. Insert pointed end of the stem into tool.
3. Place rivet in prepared hole and squeeze handles of tool.