

## Installation Instructions

### Screws – Metal / Timber

1. Choose a screw length that will allow the screw to travel through the materials being fastened (the drill point should be fully exposed after drilling).
2. When fixing timber to metal, pre-drill the timber.
3. Fit screw to driving tool. Push sharply to create 'centremark'.
4. Squeeze trigger and maintain constant pressure until screw has drilled and fastened.