

## Installation Instructions

# Security Double Eye Padbolt

1. Position padbolt and saddle in location to check that the unit will function as intended.
2. Drill 3.5mm pilot holes and fasten padbolt to gate with screws and/or carriage bolts provided using a standard screwdriver. To fit carriage bolts 6.5mm holes are recommended.
3. Fit saddle to gate post.