

Installation Instructions

Self Tapping Screws

1. Drill pilot hole or punch sheet metal.
2. Manual drive when joining sheet metal.
3. Power drive when fixing pre-drilled materials to timber.