

## Hints & Tips

## **Plasterboard Screws - Zenith**

\* When fixing plasterboard, slightly recess the head of the screw to ensure a clean, flush finish once the plaster is applied.

\* Typically 10mm plasterboard is used for wall lining and 13mm for ceiling applications.

\* When fixing plasterboard ensure fixing points are 10-16mm in from the edge.

\* Screw every 300mm, at sheet ends and around all doors and window. This means a 2400 x 1200mm sheet would require 30 fixing point per sheet including adhesive.