

## Installation Instructions

# Colonial Gate Springs

1. Position spring diagonally (corner to corner) with adjusting pin holes to top, attaching to post. Bottom gets attached to gate.
2. Fasten locating lugs with screws provided using a No.2 Phillips bit at 1,000 RPM (alternatively you can use a standard screwdriver). Mark holes for screws, drill 3mm pilot holes and fasten using screws provided and a Phillips head screwdriver.
3. Fasten top bracket first, then the bottom, making sure both brackets are close to edge.
4. To tighten spring, wind tightening nut clockwise with a spanner, and insert the stopping plate.