

Installation Instructions

D Latch

1. Position gate latch in location to check that unit will function as intended. Check that unit is at a suitable height for regular use.
2. Position latch on post and fasten using a No. 2 Phillips bit at 1,000 RPM and self-drill screws provided (alternatively you can use a standard screwdriver). Mark holes for screws, drill 2.5mm pilot holes and fasten using screws provided and a Phillips head screwdriver.
3. Fit bar to gate using same method used to attach the latch.